

Frozen Pipes

When determining the cause of loss, should your investigation determine that the loss is a result of a **frozen pipe**, further investigation is needed to assist the desk adjuster in his/her coverage determination as coverage may not be afforded for the loss.

Below are some questions to ask, however, <u>do not limit yourself</u> to these questions. Remember to obtain as much information as possible in order to assist the Client in their coverage determination.

Observations and Investigative Questions to Ask:

- 1. Confirm the date of loss with the Insured and/or their representative.
- 2. If the Insured does not know the exact date of loss, when did they first notice the loss?
- 3. What is the source of heating for the property? (Gas furnace, electric baseboards, propane tank, oil tank, et cetera.)
- 4. What pipe broke? (Supply line to sink, fire sprinkler system, et cetera.)
- 5. Where is the location of the pipe that broke. Is it an interior wall? Exterior wall? (Demonstrate this on your sketch.)
- 6. Who are the utility service providers for the property?
- 7. Were <u>any</u> of the utility services interrupted at any time prior to the loss and if so, why?
- 8. At what temperature is the property normally kept?
- 9. At what temperature was the property kept on the day of the loss?
- 10. Was the property rented prior to or on the date of loss? If so, obtain a copy of the lease.
- 11. Was the property occupied or vacant on the date of the loss? If so, when was the last time it was occupied?
- 12. Why was the property unoccupied or vacant?
- 13. How much of the property is unoccupied or vacant?
- 14. What is the temperature inside the dwelling/building upon your inspection?



Additional Photographs to Obtain:

- 1. Photograph the pipe that ruptured close up showing the rupture, and another photograph farther away to show the location of the pipe break in the room.
- 2. Photograph any work invoices for the original installation of the line that broke.
- 3. Photograph any work invoices for the repair of the broken line.

As always, be sure to include a sketch with your report. Don't forget to <u>annotate on your sketch</u> where the frozen pipe was located (i.e. exterior wall, interior wall) of the dwelling/building